

## Operating Instructions K50289 Ball-Lok / Self-Lok Tool

## Warning:

Always wear safety glasses when operating hand tool.

## Instructions:

- 1. Tool is designed to accept 3/16" and 5/16" wide coated and uncoated ties.
- Turn tension adjustment knob until desired tension setting is displayed in tension indicator window. Space between numbers counts as one-half setting. See step 7.
- 3. Extend handle open to release gripping mechanism and insert clamp tail into tool through side load entry.
- 4. Squeeze handle repeatedly to tighten band around object. Be sure to release handle completely to use full pull-up stroke of tool. Buckle must be secure against the tool head. Once the preset tension has been reached, the handle will no longer release completely.
- 5. To cut-off excess clamp tail, squeeze handle one last time.
- The tool must be reset by, extending the handle out until it snaps into place, the tool will be ready to apply the next clamp.
- 7. Tension Setting Range:

3/16" Self-Lok	0 – 4 1/2
3/16" Ball-Lok	$0 - 4 \frac{1}{2}$
5/16" Ball-Lok	0 – 6 1/2

